# LifeSmart<sup>®</sup> Simply Brilliant

Nature Mini / Nature Mini S

Setting up your LifeSmart Nature

User Guide Version 1.0



NOTE: The microphone of some models is optional, please refer to the actual product

### ILLUSTRATION

Nature Mini/Nature Mini S is a smart home control panel installed at the intersection of moving paths in your home. It has a 4-inch HD touch screen to provide you with a wide visual space and a comfortable interaction experience.

With a powerful hardware platform to support multi-mode protocols and a customized operating system, it can transmit control signals to smart home devices and receive status feedback, thus realizing control functions of smart devices such as turning off lights and opening curtains.

# SPECIFICATIONS

	Nature Mini S	Nature Mini
Operation System	Android	Linux
Screen solution	720*720	480*480
Wireless protocol	Wi-Fi, CoSS, Bluetooth	Wi-Fi, CoSS
Wireless frequency	2.4GHz/433MHz GFSK	
Wireless distance	200m (open field)	
Product size	Outside the wall: 86*86*11mm Overall: 86*86*36mm	
Working temperature	-5~45°C	
Working humidity	5~90%	
Input	AC 100-240V 50/60Hz	
Load	Resistive Load: 500W per channel. Inductive/Capacitive Load: 200W per channel.	



- L: Live line input
- N: Null line input

NOTE: The number of output lines varies according to different smart control accessories, please refer to the actual product.

WARNING: The installation involves high voltage and should be done by a professional electrician.

#### INSTALLATION

- Cut off the electrical power supply and make sure the wiring is not charged.
- ② Take out the smart control accessory and install it according to the wiring instruction, make sure all the wires are placed firmly.
- ③ For safety reasons, it is recommended to put a layer of insulating tape on the screws that fix the wires to ensure that there is no contact between the neutral and live wires to prevent short circuits. Especially for the smart control accessory installed inside the metal cassette, make sure that the screws that hold the wires do not touch the cassette.
- In Place the wires in the cassette orderly, and fix the smart control accessory to the cassette with fixing screws.

- ⑤ Take out the smart control panel and fix it to smart control accessory, make sure that the upper and lower two buckles are in place, otherwise it may not be able to be used normally due to poor contact.
- 6 Restore the power supply, the device will turns on automatically.



Thank you for purchasing this LifeSmart product. In order to protect your rights, please read the following content carefully: The warranty period of our company's products is one year from the date of purchase or longer if local laws impose a longer minimum term, in which case the minimum term is the warranty period. During the warranty period, any faults caused by the product itself or for quality problems that arise under normal usage, LifeSmart will provide a free replacement.

User support e-mail address

support@ilifesmart.com

Website

www.ilifesmart.com



Manufacturer: HANGZHOU LIFESMART TECHNOLOGY CO., LTD.

Address: 10-11th Floor, Building A, SUPCON Information, 352 Bingkang Road Binjiang,Hangzhou, Zhejiang, China

## ATTENTION

The following conditions are not covered by the warranty:

- Product failure or damage caused by installation, use, and maintenance that is not in accordance with the product instructions;
- · Products beyond the warranty period;
- · Products that have the barcode tampered with or removed;
- Devices that have been tampered with or customized outside of LifeSmart Terms Of Service as on the LifeSmart APP and website;
- User-caused damage, such as inappropriate voltage input, high temperature, accidental spillage, physical damage, etc;
- Product failure or damage caused by force majeure such as earthquakes, fires, or floods;
- Product failure or damage caused by other problems except the product itself.